产品说明书 | MANUAL

产品参数

品牌：TANCHJIM/天翔技术
型号：RITA AT
耳机容量：40-2000hz
耳机驱动：40mm高保真动圈单元
振动频率：Hz/Hzz
音量控制器：+7hz-12hz/4kb
单次续航：5小时
充电盒：5小时
蓝牙版本：Bluetooth V5.0
通信距离：10米（BT）、10M
通信协议：A2DP、AVRCP、HFP、HSP
工作温度：-10~+45度/-14~113度
耳机充电接口：Type-C
充电盒入：Type-C
充电容量：450 mAh（3.7V）/40 mAh
耳机电池：3.7V/40 mAh（3.7V）
耳机重量：5.5克（单只）
CMF认证：2149631231
FCC认证：2AYSG-RITA
耳机颜色：黑/白/蓝/粉/玫瑰金/灰
充电盒颜色：黑/白/蓝/粉/玫瑰金/灰
产品名称：天翔技术蓝牙耳机
产地：广东省广州番禺区南沙区南沙大道南沙经济区
科技研究中心一期三层

PRODUCT SPECIFICATIONS

Brand: TANCHJIM
Model: RITA AT
Frequency Response: 20-20,000Hz
Diaphragm Material: 40mm Moving Coil Driver Transducer
Diaphragm Material: PU + Titanium Coating
Total harmonic Distortion (THD): <1% @1kHz, 94dB
Impedance: 32Ω
Bluetooth Version: 5.0
Bluetooth Range: 10M (BT), 10M (BLE)
Bluetooth Profile: A2DP, AVRCP, HFP, HSP
Playback Time: Up to 5 hours (ANC Off) / 3 hours (0 min (ANC On)
Operating Range: 10 m (open space, no obstacles)
Wired Charging Port: Type-C
Charging Input: 5V/1A
Battery Capacity: 450 mAh, 3.7V, 2.405 Wh
Headset Battery: 40 mAh, 3.7V, 0.148 Wh
Headset Weight: 5.5 g (each)
CMF ID: 2149631231
FCC ID: 2AYSG-RITA
Manufacturer: Nanning Heavy Technology Co., Ltd.
Headset Color: Black/White/Blue/Pink/Rose Gold/Gray
Case Color: Black/White/Blue/Pink/Rose Gold/Gray
Product Name: Tianxiang Technology Headset
Address: Room 201, 1st Floor, Technology Innovation Center, Qili A1304, Science & Technology City, No.33 Yingfu Road, Yongning District, Nanning, Guangxi, China

製品パラメータ

ブランド：TANCHJIM/天翔技術
モデル番号：RITA AT
周波数応答：20-20,000Hz
ダイヤフラム素材：40mm高解像度ダイナミックドライバートランスデューサー
振動素材：PU + チタンコーティング
全高調波歪（THD）：<1% @1kHz, 94dB
インピーダンス：32Ω
Bluetooth バージョン：5.0
Bluetooth 範囲：10M (BT)、10M (BLE)
Bluetooth プロファイル：A2DP、AVRCP、HFP、HSP
再生時間：5時間（ANC オフ）/ 3時間（0 min (ANC オン)
動作範囲：10m（障害物なし、オープンエリア）
有線充電ポート：Type-C
充電入力：5V/1A
バッテリー容量：450 mAh、3.7V、2.405 Wh
ヘッドホンバッテリー：40 mAh、3.7V、0.148 Wh
ヘッドホン重量：5.5 g（片側）
CMF ID：2149631231
FCC ID：2AYSG-RITA
メーカー：南寧重鎮科技有限公司
ヘッドホンカラー：黒/白/青/ピンク/ローズゴールド/グレー
ケースカラー：黒/白/青/ピンク/ローズゴールド/グレー
製品名：天翔技術ヘッドホン
住所：広西壮族自治区南寧市永寧区永凱区科学技術革命センター第一期3階

常见问题

1. 为什么我的耳机了，我不记得要多长时间才能再次使用？
答：为了确保最佳性能，请定期使用耳机。如果您长时间未使用耳机，请考虑为其充电或执行重置。这有助于保持电池健康并确保连接稳定。

2. 我的耳机无法配对到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝试重置耳机。

3. 我的耳机无法连接到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝试重置耳机。

FAQ

In an open environment without obstructions, the headphones can be used normally within 10 meters of the paired device. If the distance exceeds this range or obstacles are present, audio may cut out or noise may occur.

2. Why do I need to charge the headphones? Do I need to charge them regularly?
Answer: To ensure optimal performance, we recommend regular charging. Additionally, since the headphones have been paired with your phone, they will reconnect automatically without the need for pairing again if the connection is lost. However, if you haven't used the headphones for a long time, it's best to charge them before pairing to avoid issues. If you still experience connection issues after the above steps, please try resetting the headphones.

Reset Procedure:
1. Delete the headphone's Bluetooth pairing record from the connected device.
2. Place the headphones in the charging case, open the lid, and wait for the LED to turn off. The indicator will flashes white rapidly, indicating the data pairing information has been cleared and the reset is complete.
3. The headphones will automatically enter pairing mode. Please reconnect them to your device.

よくある質問

通信距離：屋外で、障害物がない状態では、最大10メートル。屋内では、壁や家具などの障害物により、通信距離が短くなる場合があります。

2. 充電する理由は？定期的に充電する必要がありますか？
答：最適なパフォーマンスを確保するため、定期的な充電をお勧めします。また、ヘッドホンはお使いのスマートフォンとペアリングされているため、長時間使用しない場合、接続が切れる可能性があります。ペアリングを解除してから再ペアリングすることで、問題を解決できる場合があります。

3. 接続できません。どうすればよいですか？
答：ヘッドホンがペアリングされていることを確認してください。ペアリングされていない場合は、ペアリングモードに入るまでヘッドホンを充電ケースに戻してください。

常见问题

1. 为什么我的耳机了，我不记得要多长时间才能再次使用？
答：为了确保最佳性能，请定期使用耳机。如果您长时间未使用耳机，请考虑为其充电或执行重置。这有助于保持电池健康并确保连接稳定。

2. 我的耳机无法配对到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝试重置耳机。

3. 我的耳机无法连接到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝试重置耳机。

よくある質問

通信距離：屋外で、障害物がない状態では、最大10メートル。屋内では、壁や家具などの障害物により、通信距離が短くなる場合があります。

2. 充電する理由は？定期的に充電する必要がありますか？
答：最適なパフォーマンスを確保するため、定期的な充電をお勧めします。また、ヘッドホンはお使いのスマートフォンとペアリングされているため、長時間使用しない場合、接続が切れる可能性があります。ペアリングを解除してから再ペアリングすることで、問題を解決できる場合があります。

3. 接続できません。どうすればよいですか？
答：ヘッドホンがペアリングされていることを確認してください。ペアリングされていない場合は、ペアリングモードに入るまでヘッドホンを充電ケースに戻してください。

常见问题

1. 为什么我的耳机了，我不记得要多长时间才能再次使用？
答：为了确保最佳性能，请定期使用耳机。如果您长时间未使用耳机，请考虑为其充电或执行重置。这有助于保持电池健康并确保连接稳定。

2. 我的耳机无法配对到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝试重置耳机。

3. 我的耳机无法连接到我的设备。我该怎么做？
答：请确保您的设备蓝牙已开启，并将耳机放入充电盒中。如果问题仍存在，请尝試重置耳机。

FAQ

In an open environment without obstructions, the headphones can be used normally within 10 meters of the paired device. If the distance exceeds this range or obstacles are present, audio may cut out or noise may occur.

2. Why do I need to charge the headphones? Do I need to charge them regularly?
Answer: To ensure optimal performance, we recommend regular charging. Additionally, since the headphones have been paired with your phone, they will

FAQ

In an open environment without obstructions, the headphones can be used normally within 10 meters of the paired device. If the distance exceeds this range or obstacles are present, audio may cut out or noise may occur.

2. Why do I need to charge the headphones? Do I need to charge them regularly?
Answer: To ensure optimal performance, we recommend regular charging. Additionally, since the headphones have been paired with your phone, they will

1. Correct disposal of waste electrical and electronic equipment (WEEE) and symbol of the "crossed-out wheeled bin"

The crossed-out wheeled bin on WEEE means that you are obliged by law to dispose of this equipment separately from the municipal municipal waste collection system. Disposing of it in the residual waste bin, the mixed waste bin, or the municipal waste collection system is prohibited. All electrical and electronic equipment containing particular substances, accessories or consumables that are not permanently installed, these must be removed before disposing of the product and be disposed of separately as waste particular substances.

2. Ways of returning waste electrical and electronic equipment

Owners of waste electrical and electronic equipment can return them to municipal collection points or collecting waste electrical and electronic equipment free of charge. Distributors are also obliged to take back equipment, batteries or accumulators with collection points installed in product sets, retailers or dropset sellers to ensure that the waste electrical and electronic equipment is correctly disposed of. Information about collection points is available on online registry of the available collection and take-back sites: https://www.tochnology.org/

1. Data privacy

We should point out to all end-users of waste electrical and electronic equipment that they themselves are responsible for deleting all personal data from the waste electrical and electronic equipment to be disposed of.

EU | REP
SUCCESS COURIER SL
CALLE RIO TORMES NUM. 1, PLANTA 1, DERECHA, CP28039, Madrid, Madrid, 28039 Spain
successservice2@hotmail.com

UK | REP
EVATOST CONSULTING LTD
Office 113, 31 Theodorakis Street, London, United Kingdom, E1W 3AY
evatost@outlook.com

Manufacturer: Nanning Heavy Technology Co., Ltd.
Address: Room 201, 1st Floor, Technology Innovation Center, Qili A1304, Science & Technology City, No.33 Yingfu Road, Yongning District, Nanning, Guangxi, China

安全警告

1. 长期、强度使用音乐产品，都会使用听力造成损害风险。请将耳机调至适当音量。
2. 请勿在驾驶或需要注意力的场合使用耳机。
3. 为确保安全，请勿在长时间使用耳机的情况下进行剧烈运动。
4. 请勿将耳机放入潮湿环境，以免损坏电子元件。
5. 请勿将耳机放入高温环境，以免损坏电子元件。
6. 请勿将耳机放入腐蚀性环境，以免损坏电子元件。
7. 请勿将耳机放入强磁场环境，以免损坏电子元件。
8. 请勿将耳机放入强电场环境，以免损坏电子元件。
9. 请勿将耳机放入强辐射环境，以免损坏电子元件。
10. 请勿将耳机放入强光环境，以免损坏电子元件。
11. 请勿将耳机放入强风环境，以免损坏电子元件。
12. 请勿将耳机放入强雨环境，以免损坏电子元件。
13. 请勿将耳机放入强雪环境，以免损坏电子元件。
14. 请勿将耳机放入强雾环境，以免损坏电子元件。
15. 请勿将耳机放入强沙尘环境，以免损坏电子元件。
16. 请勿将耳机放入强烟环境，以免损坏电子元件。
17. 请勿将耳机放入强火环境，以免损坏电子元件。
18. 请勿将耳机放入强爆炸环境，以免损坏电子元件。
19. 请勿将耳机放入强辐射环境，以免损坏电子元件。
20. 请勿将耳机放入强光环境，以免损坏电子元件。
21. 请勿将耳机放入强风环境，以免损坏电子元件。
22. 请勿将耳机放入强雨环境，以免损坏电子元件。
23. 请勿将耳机放入强雪环境，以免损坏电子元件。
24. 请勿将耳机放入强雾环境，以免损坏电子元件。
25. 请勿将耳机放入强沙尘环境，以免损坏电子元件。
26. 请勿将耳机放入强烟环境，以免损坏电子元件。
27. 请勿将耳机放入强火环境，以免损坏电子元件。
28. 请勿将耳机放入强爆炸环境，以免损坏电子元件。
29. 请勿将耳机放入强辐射环境，以免损坏电子元件。
30. 请勿将耳机放入强光环境，以免损坏电子元件。
31. 请勿将耳机放入强风环境，以免损坏电子元件。
32. 请勿将耳机放入强雨环境，以免损坏电子元件。
33. 请勿将耳机放入强雪环境，以免损坏电子元件。
34. 请勿将耳机放入强雾环境，以免损坏电子元件。
35. 请勿将耳机放入强沙尘环境，以免损坏电子元件。
36. 请勿将耳机放入强烟环境，以免损坏电子元件。
37. 请勿将耳机放入强火环境，以免损坏电子元件。
38. 请勿将耳机放入强爆炸环境，以免损坏电子元件。